


# TYPICAL STAKE CENTER ORGAN



**STOPS-Pedal**  
Rocker tabs control the voices for the pedals.

**STOPS-Swell**  
Rocker tabs control the voices for the swell manual.

**STOPS-Great**  
Rocker tabs control the voices for the great manual.

**GENERAL MODIFIERS**  
Tabs control special features of the organ

Power Switch →

↑ Volume Indicators

**GENERAL PISTONS (1-10)**  
Turns on or off pre-programmed "stop" combinations for the ENTIRE ORGAN.

**GENERAL TOE STUDS (6-10)**  
Turns on or off pre-programmed "stop" combinations for the ENTIRE ORGAN.

**CRESCENDO PEDAL**  
Adds "stops" in pre-programmed combinations that gradually build in volume.

**PEDAL TOE STUDS**  
Turns on or off pre-programmed "stop" combinations for the PEDALS.

**CANCEL BUTTON**  
Turns off all "stops."

**GREAT EXPRESSION PEDAL**  
Controls the volume of the Great Manual

**SWELL EXPRESSION PEDAL**  
Controls the volume of the Swell Manual

**A. Reversal Piston**  
"Reverses" or "recalls" the last combination set prior to using any general or divisional piston.

**B. Swell to Great Coupler Stud/Piston**  
Couples the Swell Stops to the Great Manual

**C. Great to Pedal Coupler Stud/Piston**  
Couples the Great Stops to the Pedals

**D. Swell to Pedal Couples Stud/Piston**  
Couples the Swell Stops to the Pedals

**E. Swell Division Pistons (1-6)**  
Turns on or off pre-programmed "stop" combinations for the SWELL MANUAL.

**F. Great Division Pistons (1-6)**  
Turns on or off pre-programmed "stop" combinations for the GREAT MANUAL.